




# What is Face Anonymization?

Anonymize: remove identifying particulars or details from something for certain purposes.

Face anonymization refers to anonymizing faces to keep identity of the person's face confidential.

# HOG

The Histogram of Oriented Gradients(HOG) is a feature descriptor used in computer vision and image processing for the purpose of object detection.





# 1. Face Detection :




```
import cv2
import dlib

detector = dlib.get_frontal_face_detector()

img = cv2.imread('image.jpg')

rectangles = detector(img)
```

## 2. Face Landmarks Detection



- dlib Library
- 68 facial landmarks

# Face Landmarks Detection

## One millisecond Face Alignment



```
import cv2
import dlib

detector = dlib.get_frontal_face_detector()
predictor = dlib.shape_predictor("shape_predictor_68_face_landmarks.dat")


img = cv2.imread('image.jpg')

rectangles = detector(img)


face = max(rectangles, key=lambda r: r.area())
landmarks = predictor(img, face)
```

### 3. Find face border

Convex hull



Convex hull vs Contour





# Face Border

Convex hull

```
...  
  
landmarks = predictor(img, face)  
  
points = [(p.x, p.y) for p in landmarks.parts()]  
  
hull = cv2.convexHull(np.array(points), returnPoints=False)
```






## 4. Blending two images

### Seamless Poisson cloning


- Given vector field  $\mathbf{v}$  (pasted gradient), find the

$\min_f \iint_{\Omega} |\nabla f - \mathbf{v}|^2$  with  $f|_{\partial\Omega} = f^*|_{\partial\Omega}$  optimize:

Pasted gradient



Mask



In this method, we don't copy the values of pixels, just copy the gradient.

```
dest = cv2.imread("image1.jpg")

source = cv2.imread("image2.jpg")

mask = np.zeros(source.shape[:2], dtype=np.float32)
rect = [(23, 25), (55, 112)]
mask = np.uint8(cv2.rectangle(mask, *rect, (1.0, 1.0, 1.0), -1) * 255)

center = 641, 395

cloned = cv2.seamlessClone(source, dest, mask, center,
cv2.MIXED_CLONE)
```



## 5. Stabilization

- Stability is one of the most important part.

To avoid this shakiness Optical Flow with Lucas-Kanade Method is used.

Equation:-

$$(u,v) = (dx/dt, dy/dt)$$



## Code for Optical Flow :-

```
hull_next, *_ = cv2.calcOpticalFlowPyrLK(img_gray_prev, img_gray, hull_prev, hull)
```



THANK YOU